



LEGO



75937




WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.





LEGO.com/jurassicworld









1




2



3





4







5




6





7







8




2





9




1




2






3







10






11






12



13



Subset Quad

Used in Builds: **No** • [Edit List Details](#)

There are 41 parts in this list worth a total of approximately €3.77 (based on 41 parts) .

Import/Delete Parts

Export Parts ▾

Bulk Edit ▾

Add Part

Color ▾

Display Options ▾

100 ▾

< Prev

1

Next >

Showing 28 of 28 unique parts/colors (41 total quantity)



1x19220



1x35654



1x30031



1x93095



2x2420



2x60897



1x60470b




1x63082



2x6157



1x3039



2x3069b



1x4006



4x11209



1x47458



2x3024




2x11477



1x29120



1x29119



2x4871



1x3795



1x2412b




1x99780



1x11476



1x99206



1x15068



4x11208



1x65179



1x3023

6H46





4x
6218841



1x
4116816



2x
4547489



1x
9327



3x
3200001



1x
370001



4x
4121932



6x
4249563



3x
6013866



3x
6218822



2x
6047220



1x
6238334



4x
4567449



3x
4558168



1x
243101



2x
370101



6x
6132212



1x
4500469



2x
396001



2x
4560178



1x
6249552



5x
6106024



1x
4514791



1x
6109817



1x
383201



1x
4603472

383201



1x
4619636



4x
6019987



2x
4581225



6x
4211094



2x
4210635



3x
6167281



3x
4211060



1x
6150297



2x
4211056



1x
4211002



1x
4495931



1x
4603472



1x
6226515

4603472



1x
6171762



1x
4603191



2x
6229130



1x
4567908



1x
6171069



2x
6270003



2x
6182261



1x
4119479



4x
6199898



4x
6250270



4x
4540280



1x
6037890



1x
4162916

6226515



5x
4528981



2x
4530028



1x
6103985



2x
4569836



3x
6258407



1x
6120642



3x
6238331



1x
6278149



1x
6104130



1x
6189082



3x
6210590



3x
6210590



3x
6210590

6210590

7

11



2x
4566028

1x
6028812

1x
4502595

2x
4211445

2x
4211395

3x
4211859

3x
4541618

2x
6063616

3x
4211398

1x
4211376

6x
4211621

2x
4211444

2x
4211481

2x
6232138

3x
6056296

1x
6004990

4x
6029209

2x
6254807

6x
6007894

2x
6102449

5x
6166127

5x
4650260

1x
4211568

1x
4211349

1x
4667578

2x
6170708

1x
4211406

1x
6156492

2x
4211573

3x
4535738

5x
4211815

2x
4211564

2x
6028811

1x
6278956

1x
6146989

3x
4211389

1x
4211397

1x
4654577

2x
4211650

1x
6171067

1x
6278977

5x
4533772

1x
6102357

2x
6257593

1x
4211394

4x
6163989

1x
4278273

1x
4211357

1x
4211473

4x
4211385

2x
4211549

2x
4211807

1x
6206249

3x
4211536

1x
4568637

3x
6198932

3x
4211414

9

Customer Service
Kundenservice
Service Consommateurs
Servicio Al Consumidor

LEGO.com/service or dial

00800 5346 5555
1-800-422-5346