



CITY

60065



[LEGO.com/city](https://www.lego.com/city)





1x

1






2x

2



2x



2x


3





2x

4






2x

5



1x

6





1x

7





2x




2x



2x

8



1



2



2x




1x



1x

9





1x



1x

10



1x

11





1x




2x

12

1



2





4x



4x

13



4x





1x





1x



1x

14



1x
6100792

1x
6051511

4x
4613256

1x
6100770

1x
6100765

1x
243224

1x
6021844

1x
6018687

2x
3005744

1x
4183133

2x
4646864

2x
3005743

1x
4289538

1x
4556158

4x
4568644

2x
615726

1x
4598955

1x
4524098

1x
6100774

2x
4295260

1x
4114052

1x
4255624

1x
4505066

1x
4162916

2x
6097585

1x
6022579

2x
4211150

1x
4211219

1x
4211186

1x
4211181

1x
4224732

2x
4211503

1x
4244627

1x
6093527

1x
4261908

1x
4211045

1x
4210875

1x
4641048

4x
4211764

1x
6015890

1x
6071226

1x
4210934



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial

: 00800 5346 5555

: 1-800-422-5346