



60006






1




2



3



4



5



6



7




8




9




10



11



12




2x
4547489


1x
4173943


1x
302301


3x
4538353


1x
4556152


1x
4296997


1x
9551


1x
4599453


1x
4646527


1x
6018687


1x
6018620


1x
6018507


1x
4141349


1x
9339


1x
4567910


1x
396226


4x
4568644


1x
4516843


2x
615726


2x
3000841


2x
4646861


2x
4119483


1x
4650500


2x
4128576


1x
4296785


1x
4613003


2x
6018628


1x
6018588


2x
4594238


1x
4211628


1x
4641048


4x
4211764


1x
4211002


1x
6018686


1x
4210934


Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial


: 00800 5346 5555
: 1-800-422-5346